

# SAILFISH 360 CC | OWNER'S MANUAL



# 2025 360 CENTER CONSOLE

*chase the thrill*



**LOA Hull Only**  
**36' 0" | 10.97 M**

**Beam**  
**11' 2" | 3.4 M**

**Length Rigged**  
**38' 6" | 11.73 M**

**Fuel Capacity**  
**400 GAL | 1,514 L**

**Cockpit Depth Bow**  
**40" | 101.6 CM**

**Draft (Hull Only)**  
**18" | 45.72 CM**

**Cockpit Depth Rear**  
**30" | 76.2 CM**

**Max Horsepower**  
**1,200 HP | 895 kW**

**Dead Rise (Multiangle)**  
**22°-24°**

**Fresh Water**  
**42 GAL | 160 L**

**Bridge Clearance w/ Hard Top**  
**9' 10" | 3 M**

**Approx. Rigged Weight**  
**15,600 LBS | 7,076 KG**

**Yacht Certified**

**Person Capacity**

**10**

**Battery Capacity**

**34**

**Rod Holders (Standard)**



## STANDARD FEATURES

### Boat

- 3-Piece Construction w/ Cored Hull Sides
- Backing Plates for Radar and VHF Mounts in Hard Top
- Boarding Ladder (4-Step w/ Grab Handle)
- Built-In Rigging Tubes (from Bilge to Helm w/ Pull Tapes)
- Carbon Fiber & Kevlar® Reinforced Deck & Hull
- Closed Cell Foam Flotation
- Easy Access Electronics and Rigging Area
- Exclusive Dot Matrix Non-Skid Flooring
- Exclusive VDS Hull Design (Variable Deadrise Stepped Hull)
- Fiberglass Hard Top (w/ Vented Sun Roof & Articulating Rear Shade)
- Integrated D Channel Hard Top Frame
- Oversized Bilge Access
- Port Side Dive Door (w/ 4-Step Folding Ladder)
- Recessed SST Cup Holders (14)
- Recessed SST Cup Holders (6 - 32 oz.)
- SailTech Composite Full Length Transom
- SailTech Foam-Filled Fiberglass Stringer System
- Thru Hull Windlass System (w/ Stainless Steel Anchor, 300' of Line and 15' of Chain)
- Trim Tabs (High-Performance, Dual Ram, Heavy-Duty w/ Indicator & Built-In Auto Retract Feature)
- Walk-Thru Transom Door w/ Wave Guard Step

### Bow

- Dual USB Charging Ports (2 - Port/Starboard)
- Fully Upholstered Convertable Bow Seating and Lounge Area w/ Power Adjustable Table/Bow Filler and Fold-Away Forward Facing Backrests
- SST Low-Profile Bow Rail
- Twin Insulated 80-qt. Storage Boxes

### Electrical

- 6 Channel Amp
- 8 Spreader Lights w/ Four-Way Control
- Accessory Switch Panel w/ Circuit Breakers
- Built-In 4 Bank Battery Charger w/ LED Readout
- Compass
- Dock Side Power w/ Distribution Panel & USB Charging Port
- Fully NMEA 2K Compliant
- Fusion Stereo System w/ Rockford Fosgate LED Lighted Speakers
- Fusion Transom & Bow Remote Control
- LED Anchor Light
- LED Interior Cockpit & Bilge Lighting
- LED Navigational Flip-Up Bow Light
- Hella Underwater LED Lighting
- SST Refrigerator
- VSR Battery Charging System
- Push to Start System

### Fishing

- 2 Circulating Baitwells w/LED Lighting (32-gal Transom / 25-gal Leaning Post)
- Built-In Tackle Storage
- Cockpit Toe Rails
- In-Floor Fish Boxes (3 - w/ Advanced Vacuum Pump)
- Sea Chest Baitwell Pump System
- Recessed Rod Storage (Port & Starboard)
- SST Rod Holders
- SST Transom Rod Holders
- Tackle Storage (Port & Starboard)
- Twin 260-qt. Insulated Aft Fish Boxes

### Hardware

- Fender Cleats (4)
- Flush Mount Hinges, Latches & Deck Plates
- Heavy-Duty SST Bow & Stern Eyes
- Heavy-Duty SST Rub Rail
- Sailfish Engraved Transom Plates

### Head/Berth

- Concealed Electric Marine Head w/ Overboard Discharge
- Corian Countertops
- Fresh Water SST Sink
- Pilot's Berth
- Port Light
- Stand-Up Shower w/ Curtain
- Wood Framed Mirror, Wood Steps & Cabinetry
- Marine Deck Flooring (Foam)

### Helm

- 12-Volt DC Accessory Plug
- Dual USB Charging Ports
- Acrylic Dash Panel on Console
- Adjustable Height Standing Driving Position
- Comfort Zone Anti-Fatigue Pad
- Console Footrest
- Deluxe Walk-In Console Berth (Lockable, w/ Port Light)
- Digital Electric Steering (Mercury 350 / 400 Verado)
- Digital Electric Steering (Yamaha)
- Edson Black Ops Steering Wheel w/ Deluxe Grip & Power Knob
- Glass Enclosure w/ Vent, Wiper & Windshield Washer
- Overhead Engine Monitor (Mercury VesselView 503 or Yamaha CL5)
- Power-Assisted Hydraulic Steering (Suzuki & Mercury 300 Verado)

### Plumbing

- Automatic Bilge Pumps (2 - 2000 GPH Aft and 1 - 800 GPH Forward)
- Freshwater Engine Flush Manifold
- High-Speed Livewell Pickup
- Pull-Out Shower (3 - Bow, Head & Transom)
- Retractable Raw Water Washdown
- Self-Bailing Cockpit (w/ 2 - 6" Oval Scupper Drains w/ Collector Box)

### Seating

- 60" Hide-a-way Rear Seating
- Bow Bottom and Backrest Cushions
- Chaise Lounge Seating w/ Fold-Down Armrests
- Leaning Post (w/ 3-Person Helm Seating and 3-Person Aft Facing Seat w/ Flip-Down Armrest & Cup Holders, Cooler, Fridge, Storage, Powered Driver's Seat Slide, 12-Volt DC Accessory Plug and Landing for Rear-Facing Bottom Machine)

### Storage

- 80-qt. Carry-On Cooler
- Console Top Tackle Organizer ("CTO", w/ Dual USB Charging Ports)
- Dash Storage Pocket
- Leaning Post Glove Box w/ Dual USB Charging Ports
- Locking Coffin Box Storage
- Twin Hard Top Storage Boxes
- Under Gunwale Storage

## OPTIONS

### Boat Options

- 12V A/C System
- 18" LED Light Bar (White)-(2)
- Bow Thruster
- Chaise Lounge/Coffin Box Seat Cover
- Console & Leaning Post Covers
- Hull Side Color Matched Dash
- Yamaha Helm Master Full Maneuverability w/Joystick
- Mercury Electric Steering w/ Joystick (300 Verado)
- Mercury Joystick (350 & 400 Verado)
- Optimus Joystick (Suzuki)
- Quick X7 Offshore Stabilization System
- Rear Shade Extension
- Spot Light for Hard Top
- Two-Tone Hard Top
- Wireless Cell Phone Charger/Holder

### Electrical Options

- Batteries for Stabilizer (2) - 27 Series
- Batteries for Triples (8) - 27 Series
- Garmin GT-15M Thru Hull Transducer w/ CHIRP
- Garmin GT-17M Thru Hull Transducer w/ CHIRP
- Garmin GMR™ 18 x HD Radome
- Garmin GPSMap 943xsv (Rear Facing) w/o Transducer
- Garmin GPSMap Triple - (1) 8612xsv w/o Transducer, (2) 8612
- Garmin GPSMap Twin - (1) 8616xsv w/o Transducer, (1) 8616
- Garmin VHF Radio & Antenna
- Radar Cable & Power Cable
- Simrad Halo24 Pulse Compression Radome
- Simrad Triple NSX 3012 w/o Transducer
- Simrad Twin NSO EVO3 16" MFD w/o Transducer
- Simrad NSX 3009 (Rear Facing) w/o Transducer
- Simrad B75 Airmar Thru Hull Transducer w/ CHIRP
- Simrad B175 Airmar Thru Hull Transducer w CHIRP
- Simrad VHF Radio & Antenna

### Seating Options

- Aft Starboard 36" Folding Side Seat (in Place of Storage Cabinet)
- Utility Leaning Post w/ Fridge, Sink w/ Faucet, Corian Counter Top, Livewell, Drivers Platform & Landing for Rear Facing Bottom Machine

### Engine Options

#### Yamaha

- Triple Yamaha F300NSB2 (White)
- Triple Yamaha F350NSA2 (White)

#### Mercury

- Triple Mercury 300 Verado V8 (Warm Fusion)
- Triple Mercury 350 Verado V10 (Warm Fusion)
- Triple Mercury 400 Verado V10 (Warm Fusion)

#### Suzuki

- Triple Suzuki DF300B (White)
- Triple Suzuki DF350A (White)



sailfishboats.com

Specifications, features, equipment, options, colors, materials and trim are based on information available at time of printing and are subject to change without notice. Some accessories shown in photographs, or described, may not be standard equipment or even available as an option(s). Confirm availability of all accessories and equipment with an authorized Sailfish Boats dealer prior to purchase. © 2025 Sailfish Boats.





V1 8/12/2024



# SAILFISH 360 CC | OWNER'S MANUAL - TABLE OF CONTENTS


2. Boat Specifications
4. Trailer Measurement Chart
5. Boat Layout
6. Seating / Occupant Locations
7. Boat Safety & Warning Labels
9. Boat Safety & Warning Label Locations
10. Boat Safety & Warning Label / Navigation Light Replacements
11. Unassisted Boarding Situations
12. Battery Switch Wiring Schematic
13. Wiring Diagram Downloads
14. Fuel System Layout
15. Head & Waste Plumbing Diagram
16. Raw Water Plumbing Diagram
17. Fresh Water Plumbing Diagram
18. Air Conditioner Plumbing Diagram
19. Dash Layout
20. Ignition Switches, Engine Shut-Off Cord/Lanyard
21. Wiring & Fuel Maintenance
22. Console / Head Area
23. VSR Battery System
24. Bilge Access and Explanation
25. Bilge Pumps
26. Raw Water Washdown System
27. Freshwater Washdown and Shower System
28. Livewell Operation
29. Fishbox Pump
30. Console Top Organizer
31. Bennett Trim Tab Maintenance
32. Windlass
33. Windlass Troubleshooting Chart
34. Hard Top Layout
35. Optional Utility Leaning Post
36. Refrigerator
37. Optional Rear Facing Bottom Unit
38. Optional A/C & Heat
40. Optional Rear Shade Extension
41. Go Light Stryker LED Searchlight
42. Electronic Actuated Bow Table & Bow Filler
43. Windshield Wipers, Reservoir & Windshield Vent
44. Adjustable Helm Seat & Driving Platform
45. Optional Quick X7 Offshore Stabilization System
46. Dive Door & Boarding Ladder
47. Engine Flush System
48. Battery Charger
49. Optional Bow Thruster
50. Shore Power
51. Shore Power Panel
52. SeaChest Baitwell Pump System
53. Overhead Engine Monitor
54. UFlex Power Assisted Steering
55. Yamaha Electric Steering
56. Optional Optimus Joystick
57. Optional Mercury Electric Steering
58. Optional Mercury Joystick (JPO)
59. Pilot's Berth
60. Electronics Hatches & Description
61. Marine Head With Waste Tank (Type III MSD Waste Management System)
69. Vinyl Care and Cleaning
70. Aluminum Cosmetic Corrosion (Pitting)
71. Caring for Aluminum
72. Caring for Stainless Steel
73. Windshield Washing and Care
74. Gel Coat
76. Sailfish Boats Limited Warranty

# SAILFISH 360 CC | OWNER'S MANUAL - TRAILER MEASUREMENT CHART



Boat Model	B	C	D	E	F	G	H	I
360CC	119 in.	72 in.	36 in.	20 in.	135 in.	383 in.	417.5 in.	48 in.


# SAILFISH 360 CC | OWNER'S MANUAL - BOAT LAYOUT



KEY	DESCRIPTION
1	Thru Hull Windlass System
2	Removable Seat for Walkup Bow
3	Power Actuated Bow Table and Lounge Filler
4	Forward Facing Backrests
5	Coffin Box / Storage
6	Windshield Wiper / Washer
7	Under Gunwale Storage
8	Adjustable Height Standing Area

KEY	DESCRIPTION
10	Rear Facing Bottom Machine
11	In-Floor Fish Boxes w/Pump-out Pumps
12	Secondary Livewell
13	Built-In Dive Ladder
14	Mechanical Room
15	Optional Fold-Out Side Seat
16	60" Fold-Away Seat
17	Livewell
18	Boarding Ladder


## SAILFISH 360 CC | OWNER'S MANUAL - SEATING / OCCUPANT POSITIONS





 \*Shown with optional Aft Starboard 36" Folding Side Seat



# SAILFISH 360 CC | OWNER'S MANUAL - BOAT SAFETY & WARNING LABELS

<b>⚠ WARNING</b>	
	<p><b>Carbon monoxide (CO)</b> can cause brain damage or death.</p> <p>Engine and generator exhaust contains odorless and colorless carbon monoxide gas.</p> <p>Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsiness, and lack of consciousness.</p> <p>Get fresh air if anyone shows signs of carbon monoxide poisoning.</p> <p>See Owner's Manual for information regarding carbon monoxide poisoning.</p> <p>NW-204-14</p>

<b>⚠ DANGER</b>	
	<p><b>Carbon monoxide (CO)</b> can cause brain damage or death.</p> <p>Engine and generator exhaust contains odorless and colorless carbon monoxide gas.</p> <p>Carbon monoxide will be around the back of the boat when engines or generators are running.</p> <p>Move to fresh air, if you feel nausea, headache, dizziness, or drowsiness.</p> <p>NW-206-14</p>

<b>⚠ DANGER</b>	
<ul style="list-style-type: none"><li>• <b>CONTACT WITH A SPINNING PROPELLER WILL CAUSE SERIOUS INJURY OR DEATH.</b></li><li>• <b>SHUT OFF ENGINES</b> while people are in the water near the boat, on the swim platform, or on the boarding ladder.</li><li>• <b>NEVER OPERATE IN REVERSE TOWARD A PERSON</b> in the water.</li></ul>	 <p>NW-300-23</p>

<b>⚠ DANGER</b>	
	<p><b>CONTACT WITH A SPINNING PROPELLER WILL CAUSE SERIOUS INJURY OR DEATH.</b></p> <p><b>STAY CLEAR OF BOAT AND STAY OFF SWIM PLATFORM AND BOARDING LADDER WHILE ENGINE IS RUNNING.</b></p> <p>NW-301-23</p>

As a boat owner, you need to become familiar with the locations of the Caution, Warning and Danger Labels found on your boat in order to ensure your safety, as well as everyone on board.

These are images of the labels to help you maintain and operate your boat safely.

7

**(California Only)**

<b>⚠ WARNING</b>
<p>Operating, servicing and maintaining a recreational marine vessel can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, service your vessel in a well-ventilated area and wear gloves or wash your hands frequently when servicing this vessel. For more information go to <a href="http://www.P65warnings.ca.gov/marine">www.P65warnings.ca.gov/marine</a>.</p>

## Warning Labels Continued






The safety for you and everyone on board, as a boat owner, you need to become familiar with and the locations of the Caution, Warning and Danger Labels found on your boat.

Below are images of the labels to help you maintain and operate your boat safely.





# SAILFISH 360 CC | OWNER'S MANUAL - BOAT SAFETY & WARNING LABEL LOCATIONS



# SAILFISH 360 CC | OWNER'S MANUAL - WARNING LABELS & NAVIGATIONS LIGHTS

If any of your Boating Safety or Warning Labels become damaged, please call Sailfish Boats' parts department for replacement stickers at 229-377-2125.

Your vessel comes equipped with navigation lights that meet or exceed all Coast Guard Requirements.

Never modify navigation lights.

Additional lights should not be installed, as they could diminish the visibility of navigation lights or be confusing to other boaters.

Navigation Lights should be replaced when intensity becomes diminished or the lights fail.

For proper replacements, please call Sailfish Boats' parts department for replacement lights at 229-377-2125.



## THE SAILFISH PROMISE

Sailfish is committed to building **practical, purposeful, powerful boats** that deliver a premium boating experience without a premium price tag. Our customers and dealers know that our **build quality and safety are unsurpassed**, and our feature sets reflect intentional choices born of deep expertise. With our strong fishing heritage, we are **passionate about empowering anglers** for success while recognizing that those anglers deserve the **comfort, convenience and versatility to maximize their family's enjoyment** of the water.







## SAILFISH 360 CC | OWNER'S MANUAL - UNASSISTED BOARDING

When using the ladder in an unassisted boarding situation, reach over the transom and open the covering board lid that is covering the ladder, pull ladder towards you, by picking up the ladder by the steps, release the strap, deploy the four step ladder by rotating it to the down position. Use your hand or foot to fully extend the ladder in the down position. Use the grab handle and ladder to board your boat. When fully onboard, be sure to place the ladder back in the storage position by reversing the deployment process.





# SAILFISH 360 CC | OWNER'S MANUAL - BATTERY SWITCH WIRING DIAGRAM




The wiring diagrams are available for download as individual .jpg files, or in a combined PDF file from the [Seminole Marine Public Google Drive](#).


- Amerishade Weathertight Switch Box Wiring
- Amerishade Switch Box Programming Instructions
- Bow Table Actuator Wiring
- 120V 60Hz Breaker Panel
- 220V 50Hz Breaker Panel (Overseas Boats)
- Aft Hull Harness
- Battery Switch Diagram
- DC Breaker Panel Diagram
- Forward Hull Harness
- Hard Top Switch Panel Diagram
- Hard Top Wiring Harness Diagram
- Head Light Switch
- Head Liner Harness
- Helm Ground Block Assembly
- Helm Switch Panel Diagram
- Leaning Post Harness
- Leaning Post Switch
- Seat Slide Switch
- Table Lift Switch

13

SAILFISH 360 CC | OWNER'S MANUAL - FUEL SYSTEM LAYOUT




KEY	DESCRIPTION
1	Fuel Filter Access
2	Fuel Fill
3	Fuel Tank Location
4	Fuel Pickups
5	Fuel Sender
6	Primer Bulbs





## SAILFISH 360 CC | OWNER'S MANUAL - HEAD & WASTE PLUMBING DIAGRAM




- 1. Overboard discharge seacock
- 2. Waste tank
- 3. Marine head
- 4. Waste tank pumpout
- 5. Waste tank vent

15

[Download Hi Resolution Diagram](#)

## SAILFISH 360 CC | OWNER'S MANUAL - RAW WATER PLUMBING DIAGRAM




16

- 1. Raw water pickup
- 2. Leaning post baitwell pump
- 3. Transom baitwell pump
- 4. Transom baitwell aerator

- 5. Seachest
- 6. Raw water washdown pump
- 7. Raw water retractable hose
- 8. Leaning post baitwell aerator

[Download Hi Resolution Diagram](#)

# SAILFISH 360 CC | OWNER'S MANUAL - FRESHWATER PLUMBING DIAGRAM



17


- 1. Fresh water fill
- 2. Fresh water transom shower
- 3. Fresh water pump
- 4. Head Sink/shower

- 5. Marine head
- 6. Leaning post faucet (Optional Utility Leaning Post)
- 7. Fresh water tanks

[Download Hi Resolution Diagram](#)



# SAILFISH 360 CC | OWNER'S MANUAL - AIR CONDITIONING PLUMBING DIAGRAM




18

- 1. A/C Pump Seacock
- 2. Water Strainer
- 3. A/C water pump
- 4. Air Conditioner Unit

5. A/C Discharge

[Download Hi Resolution Diagram](#)

# SAILFISH 360 CC | OWNER'S MANUAL - DASH LAYOUT



	DESCRIPTION
1	Compass
2	Optional Multi-Function Displays
3	Switch Panels
4	Fusion Stereo
5	Trim Tab Actuator Switches
6	Binnacle
7	Driver's Power Seat Slide Switch
8	Windlass Switch
9	Optional A/C Dash Vents
10	Tilt Helm
11	Optional Remote Spot Light Control
12	Ignition Panel
13	Optional VHF Radio
14	Optional Joystick Steering

## Ignition Switches, Engine Shut-off Cord/Lanyard

Each Sailfish boat will be equipped with an ignition switch with an emergency engine shut off cord/lanyard.

This lanyard should be worn at all times while operating the vessel, if the vessel operator falls or moves a unsafe distance away from the helm controls the lanyard will pull out causing the engine to shut down.

Make sure the lanyard is not attached to a part of your clothing that could be easily torn free causing the switch not to pull. See your YAMAHA, MERCURY or SUZUKI owner's manual for more information on this safety feature.

## Engine Break-In Period

Each new outboard motor will need to go through a break in period to make sure all of the internal moving parts and components have a chance to correctly mate.

For more information on the break in period specific to your engine please refer to your YAMAHA, MERCURY or SUZUKI Owner's manual. .





## Plug and Play Wiring

Deutsch Connectors are quick disconnect plugs used for durability and ease of replacing components in your Sailfish Boat.

These water resistant plugs are for use in electrical systems where moisture, salt spray, dirt and dust could affect the electrical connections or systems.



## Fuel-Water Separator

Sailfish installs water fuel separators in the bilge compartment on all models rigged with Yamaha & Suzuki engines. Each engine will have its own filter, which can be accessed through the bilge access doors in the back of the boat.

On Sailfish boats rigged with Mercury engine(s), the fuel-water separator(s) may be built into the engine - depending on the engine Model.

For more information on these filters, please review your Yamaha, Mercury or Suzuki Owner's Manuals.

SAILFISH 360 CC | OWNER'S MANUAL - CONSOLE / HEAD AREA



KEY	DESCRIPTION
1	Large panel for easy access to Console Components
2	Breaker Panel
3	Battery Selector Panel
4	Windlass Breaker

KEY	DESCRIPTION
5	Battery Storage and Access Hatch
6	Fresh Water Sink w/ Pull-Out Shower
7	Soap Dispenser
8	Storage / Optional A/C Unit Compartment

# SAILFISH 360 CC | OWNER'S MANUAL - VSR BATTERY SYSTEM

The VSR, or Voltage Sensitive Relay, is a very handy little box that solves a load of traditional charging problems on marine electrical systems. It essentially serves as a smart battery switch deciding automatically when either one or more batteries are charged – or discharged. It works great on almost any boat with multiple batteries – and eliminates all of the guesswork that used to come with manual battery switches.

## What a VSR does

The VSR is installed between two batteries. Many People are surprised to learn that it is NOT connected to either the alternator or charger output wires! Its setup is much more clever.

It either battery goes above 13.7 volts (due to either alternator or charger output), the VSR connects both batteries together. Both batteries are now charging – without the boat ever having to throw a switch. Alternately, when the system voltage drops back below 12.6 volts, i.e., no more charging, the relay opens and the batteries are separate. This means that both batteries now discharge independently.

## How a VSR changes real world boating

Let's say that a fishing boat has a two or three battery setup. As is often the case, one of the batteries is dedicated to an important job – starting the engine. The other battery is used for other operations.

As the fisherman runs the boat from hole to hole, the engine alternator elevates the voltage to the cranking battery above 13.7 volts. This triggers the VSR to automatically connect a starting battery and house battery together. Both are now charging.

Upon reaching his destination, the boater kills the engine – and the alternator output. Because of the lowered voltage, the VSR now disconnects the batteries. Because he is now discharging only one battery, our fisherman is going to have starting power when he needs it later. Once underway again, the alternator power causes the VSR to reconnect the batteries and begins replenishing the house battery.

23





## SAILFISH 360 CC | OWNER'S MANUAL - BILGE ACCESS & EXPLANATION

The bilge of your boat can be accessed through the large lid in the floor aft of the leaning post. This lid allows easy access to many of the boats components.

You may also access it through the access plates in the splash-well.



24

**The bilge area of your Sailfish boat should be checked before, during and after each operation.**

## SAILFISH 360 CC | OWNER'S MANUAL - BILGE PUMPS

All Sailfish Boats are furnished with Auto-Sensing Bilge Pumps, which are engaged when the water level rises in the bilge and the causing the pump to turn on until the water level falls to a sufficient level.

These pumps can be tested by turning them upside down, the pump should turn on, once turned back over it will run for a few more seconds and then shut off. The pumps also have a manual switch function on the main switch panel which when engaged, will cause the pump to run until the switch is turned off.

The auto function of the pumps are wired into your boat bypassing the battery switch so that they have power at all times, this safety feature will counter water intrusion (up to the capacity of flow of the system) while you are away from the boat and the batteries are turned off.

The manual switch function is powered through the battery switch to prevent the pumps from remaining on accidentally by inadvertently leaving the switch on.

The Sailfish 360CC is equipped with two Aft - 2000GPH pumps and a midship - 800GPH pump.

Never leave your vessel unattended while in the water for long periods of time and always monitor your batteries voltage level and bilge water level.

**WARNING** — The bilge pumping system is not designed for damage control.




25

## SAILFISH 360 CC | OWNER'S MANUAL - RAW WATER WASHDOWN SYSTEM

The raw water washdown on your Sailfish Boat is powered by a Shur-flo Pro Blaster Pump which creates a pressurized system, once the pump is turned on and pressure is created the pump will shut down until more pressure is needed. The raw water washdown pump can be accessed through the center lid in the floor, aft of the leaning post.

**THIS PUMP HAS A BUILT-IN STRAINER THAT MUST BE CHECKED AND CLEANED REGULARLY TO MAINTAIN PROPER FUNCTION.**

To operate make sure the seacock is in the open position. The hose fitting for the washdown is located under the gunnel, mid-ship on the starboard side, to use simply pull out the retractable nozzle and turn the switch on. Pressure will build up in the hose and the nozzle and as you spray the pump will continue to engage as needed.





## SAILFISH 360 CC | OWNER'S MANUAL - FRESHWATER WASHDOWN & SHOWER

The freshwater washdown and shower system on your Sailfish Boat is powered by a Shur-flo Pro Blaster Pump which creates a pressurized system, once the pump is turned on and pressure is created throughout the freshwater hoses; once they are all pressurized the pump will shut down until more pressure is needed.

**THIS PUMP HAS A BUILT-IN STRAINER THAT MUST BE CHECKED AND CLEANED REGULARLY TO MAINTAIN PROPER FUNCTION.**

All of the freshwater systems on the boat will operate on this system once the freshwater switch is engaged.

You should allow a few seconds for the system to prime and pressurize before attempting to use any of the showers/sinks ect.

The freshwater holding tanks are located behind the pump house compartment in the bilge area.

The fill for this tank is located on the gunnel, aft starboard side of the vessel just below the motor flushing system hook-up. The freshwater pump can be accessed through the lid in the center of



27

## Instructions

- Make sure the seacock below the baitwell pump is in the open position (seacock is accessed through the hatch under the transom walk thru door).
- Turn on the livewell switch.
- Adjust the black aerator in the livewell to the desired flow (if your model has a livewell in the leaning post you can adjust the aerator to pump water into the transom livewell or the leaning post livewell or both)
- In order to fill the livewell, reach in the access hatch below the livewell and close the red handle ball valve.
- The livewell will fill up until it reaches the Overflow built into the side of the livewell. This allows the water to continually pump in and drain out while maintaining the water level.
- To drain the livewell open the red handle ball valve.
- LP livewell has a black drain plug. Insert it in the bottom drain fitting and turn livewell switch on.



28



# SAILFISH 360 CC | OWNER'S MANUAL - FISHBOX PUMP

The 360 CC is equipped with two diaphragm pumps called the gulper grouper (pictured to the right). The Whale Gulper Grouper pump has no impeller to clog or burn out. Unlike impeller pumps these have no-choke valves that easily pump out fish box waste.

They also offer long term durability, they can run dry without causing damage.

## Troubleshooting

Electric Motor Runs but doesn't pump

- Disconnect pump and turn off all power.
- Disconnect hoses and unscrew housings.
- Check entire hose system for blockage.
- Inspect tricuspid valves for blockage or inverted valve(s).
- If valve(s) are blocked, remove blockage, re-assemble the pump and continue use.
- If a tricuspid valve is inverted, replace with a new tricuspid valve, reassemble the pump and continue use.

If the electric motor will not operate, check that:

- The isolator switch is on.
- There is 12 volts at the battery terminals.
- The in-line fuse / circuit breaker are operational.

If the fuse / circuit breaker has blown, check for debris in pump head and clean out if necessary. Replace the fuse or re-set circuit breaker and run the pump.



29



## SAILFISH 360 CC | OWNER'S MANUAL - CONSOLE TOP ORGANIZER ("CTO")

The console top organizer is a great place to store almost anything. It also includes a dual USB charging receptacle.

Always store the organizer with the lid closed and the spring positioned as it is in the picture to the right.

When possible, store covered out of sunlight to avoid UV damage to the lid.



30

KEY	DESCRIPTION
1	Lid Spring
2	Dual USB Charging Receptacle



# SAILFISH 360 CC | OWNER'S MANUAL - BENNETT TRIM TAB MAINTENANCE

## ELECTRICAL CONNECTIONS

- Periodically, check for clean electrical connections on all components.

## COLD TEMPERATURES

- Cold temperatures do not affect the trim tab system. No winterization is necessary.

## SACRIFICIAL ANODES

- To deter electrolysis, a sacrificial anode should be attached to the top of each trim tab. The anode must make direct contact with the stainless steel trim tab. Do not paint the anode. Do not ground trim tabs to other underwater appendages.

## PAINT TRIM TABS TO DISCOURAGE MARINE GROWTH

1. Clean surface of all grease, oil, dirt.
  2. Apply two coats of epoxy metal primer.
  3. Apply two coats of anti-fouling paint. Actuator, including the piston, may be painted.
- Unpainted trim tabs may acquire an orange discoloration. THIS OXIDATION OF SURFACE CARBON MOLECULES IS NORMAL. The integrity of the stainless steel is not affected. Orange coating can be cleaned off, but may eventually return. NOTE: This discoloration should not be confused with the pitting and corrosion of electrolysis.

## MAINTENANCE PRECAUTIONS

- Take immediate action to correct any malfunction or failure of your trim tabs.
- Occasionally, check for loose or corroded wiring connections.
- Stepping on the trim tab may cause damage to the unit, or injury.
- Leaving the actuator extended when boat is not in use will NOT cause seal damage.

## OPERATION PRECAUTIONS

- Do not over-trim, particularly at high speeds as the bow will dig in and wave action may cause the boat to veer.
- While underway, do not move one trim tab significantly farther down than the other as undesirable listing could occur.
- Use your trim tab helm control with caution.
- For best maneuverability, trim tabs should be fully retracted in a following sea, or when running an inlet.
- Improper use of trim tabs can cause an accident or injury. Bennett Trim Tabs have a significant effect on the operation and versatility of your boat. No one knows your boat better than you. The best learning method is to spend time getting familiar with your boat's reaction to the trim tabs. As your experience with Bennett Trim Tabs increases, so will your enjoyment. Always operate your boat with safety first in mind.

31



 **SAILFISH**  
BOATS

Your boat has a factory installed windlass and there will be a complete owners' manual in your owners packet. For more detailed information please refer to your windlass owners manual. The remote will be stored forward in the windlass hatch.

Included on this page are some maintenance recommendations and a troubleshooting guide.

## Maintenance

### General Recommendations

- After the first two or three anchor recoveries, check the mounting nuts to ensure that the windlass is still fastened tightly to your deck, as it should now be bedded-in.
- Regularly wash down the exterior of your windlass with fresh water.
- Examine all electrical connections for possible corrosion, clean and lightly grease as necessary.
- Anchor rode splice should be checked regularly and remade if there is any evidence of wear.
- The Gypsy should be examined on a regular basis, because it is a high wear item. The Gypsy is designed for short scopes of chain and will last longer if properly used.



The windlass breaker is located in the head/console compartment.

## Troubleshooting

### Anchor Rode pays out independently while windlass is not in use

This problem is a result of not securing the anchor rode combined with the Gypsy Drive Cap being slack. Tighten the Gypsy Drive Cap using the tool provided and always secure the anchor rode independently of the windlass whenever it is not being deployed or recovered.

### Electrical Troubleshooting

As with most electrical marine equipment the majority of problems that arise are electrical in nature. Therefore it is essential that the proper voltage be maintained. The proper voltage on a 12 Volt system is 13.5 Volts. (Constant low voltage will destroy the motor). Ensure that electrical cable size is large enough to handle the current draw imposed upon it and keep the voltage drop within acceptable limits. In any circumstance voltage drop due entirely to cable resistance should not exceed 10%.

Follow the charts on the following page to troubleshoot the problem.



# SAILFISH 360 CC | OWNER'S MANUAL - WINDLASS TROUBLESHOOTING CHART

## Failure to Operate Troubleshoot Chart: Reversing Toggle Control Switch (Part No. 0052519)


Is there voltage at the input terminal (positive) to the control switch?	If no voltage is present, the battery isolation is OFF, the breaker is tripped or a fuse has blown. The battery may also have been dead or disconnected.
<b>Yes ▼ No ►</b>	
Check voltage at the output terminals of the control switch with the switch on forward then reverse.	Control switch is defective.
<b>Yes ▼ No ►</b>	
Replace Motor	

## Sluggish Operation Troubleshoot Chart

Is windlass overloaded?	Ease the load and ensure the battery is well charged.
<b>Yes ▼ No ►</b>	
Check the voltage across the motor leads with the windlass on. (Proper voltage is 13.5V. Constant low voltage will destroy the motor).	There is a severe voltage drop in the circuit.  Check for undersized cables, poor connections or corroded connections. Also check for resistance across the battery isolation switch or solenoid. (Feel them to see if they are heating up).
Is the voltage low? (Below 11.0V on a 12V system?)	
<b>Yes ▼ No ►</b>	
Is the voltage correct? (Above 11.0V and anchor is not fouled).	The motor is defective. Replace the motor.
<b>Yes ▼ No ►</b>	

33

SAILFISH 360 CC | OWNER'S MANUAL - HARDTOP LAYOUT



The hard top is equipped with courtesy lights, spreader lights, docking lights, an anchor light, two speakers and overhead storage boxes.

KEY	DESCRIPTION
1	Power Vent
2	Power Aft Shade
3	Hard Top Lighting Switch Panel
4	Brand Specific Motor Guage
5	Windshield Wiper w/ Washer
6	Optional Rear Facing Camera
7	Overhead Fully Vented Sun Roof & Hatch

## SAILFISH 360 CC | OWNER'S MANUAL - OPTIONAL UTILITY LEANING POST



Utility Leaning Post comes with 12v Fridge, Corian Counter Top, Tackle Storage, Tackle Organizer, Livewell & Landing for Rear Facing Bottom Machine.

35







The Refridgerator auto senses the power supply available and will run off of the 120V Shore Power System if the power is present. If the shore power is disconnected or while underway, the fridge will default back to drawing power from the 12V House System.

To turn the fridge off, turn the thermostat to the highest temperature setting.

## Isotherm CRUISE 42 Stainless Steel (INOX) Small CRUISE Marine Fridge

The Isotherm Cruise 42 Stainless Steel is a unique refrigerator that can fit locations with limited depth because of its remote-mount compressor. The CR42 has 1.5 cubic feet of storage with room for tall bottles to stand upright inside the fridge due to its 'right-sized' freezer compartment.

- Volume: 42 liters (1.5 cubic feet)
  - Silent, highly efficient, fan cooled 12/24V Danfoss / Secop remote-mount compressor (type DB35F)
  - Mounting frames for a complete flush integration
  - 316 grade brushed stainless steel doors
  - Exclusive, complete stainless steel design (doors and handles)
  - 4 liter 'right size' freezer compartment allows tall bottles to stand upright in fridge interior
- [For More information, click here](#) or check your Owner's Packet for your user manual.

## SAILFISH 360 CC | OWNER'S MANUAL - OPTIONAL REAR FACING BOTTOM UNIT



### Optional 9-inch Multi Function Display

- 9-inch high-resolution intuitive touchscreen controls
- NMEA 2000® and NMEA 0183 support for network connectivity, including autopilots, digital switching, weather, FUSION-Link, VHF, AIS and more



## SAILFISH 360 CC | OWNER'S MANUAL - OPTIONAL AIR CONDITIONING & HEAT



38

KEY	DESCRIPTION
1	Heat & Air Vent
2	Heat & Air Control Panel
3	Location of the Heat & Air Unit



## Operation of the A/C Unit

- The Airconditioning unit runs off of the 12V House Battery System and is plumbed to require raw water circulation.
- Ensure the Seacock is open and the House Battery System is turned on.
- Turn on the unit from the control panel inside the head. You can adjust temperature and fan speeds.
- After turning on, monitor the system to ensure the water is being discharged from the vessel (Mid-ship STBD)
- Adjust the baffles at the helm and inside the head to direct the air flow to desired locations.

**NOTE** – Periodically check and clean the strainer located inside the midship bilge. The water intake line needs to remain free of trash and debris to ensure the pump and unit can cool to the proper levels.







## Go Light Stryker® LED Searchlight

- 10 High Flux LED's
- Wireless or Hardwired Remote Control Options
- Permanent or Portable Mounting Options
- 370° Rotation x 135° Tilt
- 410,000 Candela, Max Beam Distance 4,200 ft
- 2.8 amps at 13.8V
- 8° Beam Angle
- UV Ray and Saltwater Resistant
- Weather Proof for Land and Sea Applications



Console Mounted Controls

## SAILFISH 360 CC | OWNER'S MANUAL - ELECTRONIC ACTUATED BOW TABLE



**CAUTION** – DO NOT STAND ON TABLE DURING ACTUATION. TABLE CAN BE USED AS A STANDING PLATFORM WHILE NOT BEING ACTUATED IN ANY HEIGHT POSITION, BUT STANDING ON DURING MOVEMENT CAN DAMAGE MOTOR.



## SAILFISH 360 CC | OWNER'S MANUAL - WINDSHIELD WIPERS, RESERVOIR, & VENT



Windshield washer fluid tank can be accessed by opening up the four hatches that gives you access to the back side of the dash. Washer fluid tank will be located directly under the onboard built-in battery charger.

43



## SAILFISH 360 CC | OWNER'S MANUAL - ADJUSTABLE HELM SEAT



Helm Seat Slide Switch

44







## SAILFISH 360 CC | OWNER'S MANUAL - DIVE DOOR AND BOARDING LADDER





# SAILFISH 360 CC | OWNER'S MANUAL - ENGINE FLUSH SYSTEM

## Operating the Engine Flush System

- Attach the blue adapter to the freshwater supply.
- Insert the adapter into the top Aquor port and twist to lock into place.
- Turn on Water Supply and flush for recommended time according to engine manufacturer's recommendations
- After flushing the first engine, turn off water supply, remove adapter and transfer to the next aquor port.
- Repeat above steps for each of the three engines.

NOTE: Each Aquor port is directly plumbed into the engine flush system through the engine's rigging tubes. This allows for a more ergonomic connection to assist in boat lift and in water situations.





# SAILFISH 360 CC | OWNER'S MANUAL - BATTERY CHARGER



## Operating the On-board Built-in Battery Charger

- Plug your dockside cord into your dockside power supply
- Plug the other end of your dockside cord into your shore power socket, secure it by twisting the ring nut to the socket.
- Check your shore power panel for correct polarity, red light located lower left of the shore power panel
- Make sure that the green light is illuminated, which will show you have power coming in
- Switch on the main shore power panel switch, top center switch
- Switch on the battery charger switch, second rocker switch down
- You can check the charging status of your batteries by rotating the DC status switch on the right hand side of the shore power panel
- Battery charger will automatically switch from charging to maintenance mode once batteries are fully charged
- To end this process, just do the reverse of this order



## SAILFISH 360 CC | OWNER'S MANUAL - OPTIONAL BOW THRUSTER



The optional bow thruster is an electrical propulsion device unit that provides lateral thrust to help with maneuverability of the bow. The bow thruster pushes a boat's bow sideways in either direction through the water using suction to draw in water from one side of the boat and push it out the other side to move the bow sideways (port or starboard).

49

The bow thruster gets its voltage from one of the engine batteries. To operate the bow thruster, engine battery switches in the on position and simply push the power button on the joystick panel and use the joy stick to maneuver the bow to port or starboard.

## SAILFISH 360 CC | OWNER'S MANUAL - SHORE POWER SYSTEM



Your shore power system starts at the dock power pedestal.

The conventional system on your Sailfish boat and your local marina combines two circuits with circuit breakers rated at 30A, two female receptacles, and a hinged lid to keep water off the connection.

These receptacles have a threaded ring that allows the shore power cord to connect securely and make a waterproof connection. Your vessel was shipped with a 30A 25' yellow shore power cord. The contacts on the plug will only fit one way into the receptacle, which prevents polarity problems.

50

### TO OPERATE OFF OF THE AC SHORE POWER:

- Connect Shore Power receptacle to the dockside shore power pedestal. Ensure plug is properly inserted and locked using the threaded rings to prevent the cord from pulling loose.
- Turn on AC Main switch, top center of the shore power panel.
- Verify the Shore Power LED turns on, and the reverse polarity LED is not illuminated.
- Engage the individual breakers for the desired functions at the 120V Shore Power Panel.


### NOTE:

Your shore power systems only work when you are plugged in to an external source of AC (120V) power at the dock.

While underway and not being supplied by 120V shore power, the fridge will operate off of the House Battery System which is charged by the engine alternators.



# SAILFISH 360 CC | OWNER'S MANUAL - SHORE POWER PANEL



MAIN DISTRIBUTION PANEL

51

**NOTE:** When in use, the shore power panel will control and display both the 12V and 120V circuits

## 120V Circuit

- Main Shore Power Input Voltage & Breaker
- Shore Power Voltage & Reverse polarity Indicators
- Breakers for individual 120V circuits

## 12V Circuit

- Remote Switches for Battery Switch Control
- Voltage readouts with selector dial for each circuit

**CAUTION** – To avoid electrical shock while servicing and or making repairs to your shore power system, make sure that the dock side power source is unplugged.

**CAUTION** – Be careful when recharging and disconnecting/reconnecting batteries. When disconnecting the cables from the old battery, disconnect the negative first, then the positive. Connect the new battery in the reverse order, positive then negative.

**CAUTION** – Be careful when connecting/disconnecting shore supply power.

**WARNING** – Do not swim close to a craft while connected to shore power.





52

The SeaChest is basically a plumbed box installed in the bilge below the water line. It has a single supply hose that floods the watertight box and also has a vent tube to allow the air out the box. The SeaChest contains two livewell pumps that delivers clean, bubble-free seawater to the individual livewells. It helps to remove air and prevent air locks, and keeps the pumps constantly submerged, so they run cooler and last longer.

To operate this system, open up the raw water seacock valve and that will allow the water to flood the SeaChest box. Turn on either or both Baitwell switches and the seawater will be pumped to the baitwells.

## SAILFISH 360 CC | OWNER'S MANUAL - OVERHEAD ENGINE MONITOR



53

Located center, above your helm position, you will find your brand-specific engine display. Please refer to your engine's owners manual for capabilities and use of this display. You will also be able to configure your optional Multi-Function Displays (if equipped) to show various engine diagnostics and functions.



Standard on Triple Suzuki engines, MasterDrive™ is a power assisted steering system operated by an electrohydraulic pump which delivers fingertip control regardless of speed or torque conditions, ensuring full control of the boat both during maneuvers and in bad sea conditions.

The MasterDrive™ is made up of three main components: helm, power unit and user interface. The user interface, which is located on the boat dashboard, allows the boater to select three different power modes according to the sailing conditions:

- Fishing
- Cruise
- MasterDrive™



# SAILFISH 360 CC | OWNER'S MANUAL - YAMAHA ELECTRIC STEERING

Helm Master EX offers boaters customizable, integrated boat control with more ease and convenience than ever before.

**Yamaha's Digital Electronic Steering (DES)** is the electronically controlled steering system is the Industry-first integrated electric steer-by-wire system. Unlike aftermarket steering systems, it is digitally connected from the helm to the engine. It offers stable and assured steering and also steering setting can be changed depending on various boating situations.

For more information on the use of your Yamaha Helm Master EX steering system please refer to your Yamaha owner's manual or view supplemental videos at <https://yamahaoutboards.com/owner-center/videos/helm-master-ex/>

**Optional Equipment shown: Joystick & Autopilot.**



55

## SAILFISH 360 CC | OWNER'S MANUAL - OPTIONAL OPTIMUS JOYSTICK (SUZUKI ONLY)



The Dometic Optimus 360 Joystick Control brings a whole new level of precision to your boat's steering. This intuitive, retrofittable joystick allows you to move not only forward and back, but also sideways. With additional features including a sensitive touch function and Take Command mode, the Optimus 360 lets you direct and rotate your boat with confidence and control.

Optimus 360 is designed for low speed maneuvering, and really excels in the marina, when pulling in and out of your slip, or docking. Optimus 360 uses intelligent programming to minimize the amount of shifting required to complete a maneuver.

56



## Electric Advantage

With no hydraulics, you get more space in the utility compartment of your boat and a cleaner transom installation. Electric Steering also minimizes noise and distraction – a meaningful benefit for Joystick Piloting for Outboards (JPO) applications, when the engines are actively holding the boat in position or maneuvering the vessel.

## Exceptional Control

Enjoy instantly responsive handling and precise, smooth maneuvers.

**Standard on V10 Verado, Optional on V8 Verado Configurations.**



(Shown above with Twin engines. Actual application on the 360 is Triple engines.)

# SAILFISH 360 CC | OWNER'S MANUAL - OPTIONAL MERCURY JOYSTICK (JPO)

## Full 360 degree control. Right at your fingertips

Move sideways, diagonally or spin the boat on its own axis. Dock in close quarters without being concerned about wind or current. Easily load the boat on a trailer. Throttle, shift and steering - right at your fingertips.

## SKYHOOK Digital Anchor

A digital anchor that locks in your boat's position and heading via GPS with the push of a button.



VesselView 703







59

Located beneath the daybed, there is a close-out panel that provides access to the following items:

- Midship Bilge Pump
- Optional Air-conditioner raw water seacock and strainer
- Black Water Holding tank and overboard discharge seacock

**Check this bilge compartment regularly.**

## SAILFISH 360 CC | OWNER'S MANUAL - ELECTRONICS ACCESS HATCHES




Located on the Aft of the Head Interior, there are two sets of hatches which allow easy access to your system components for maintenance and or servicing.



Located in this cabinet will be items such as the battery charger, the stereo amplifier, circuit breakers, and electrical connections for the engine control system.


60

SAILFISH 360 CC | OWNER'S MANUAL - TYPE III MSD WASTE MANAGEMENT SYSTEM





KEY	DESCRIPTION
1	Battery
2	Fuse
3	Waste Management System
4	Master Switch
5	Controller for Waste Management System

KEY	DESCRIPTION
1	Vent
2	Inlet
3	Toilet
4	Deck Pump Out
5	Overboard Discharge
6	Waste Holding Tank
7	Outlet



Dometic MasterFlush



Components

Installed toilet (fig. 1)

Ref.	Description
A	Macerator toilet
B1	DFS-2F flush switch (standard - freshwater flush toilet)
B2	DFS-1F flush switch (standard - sea water flush toilet)
NS	DFST flush switch (optional) NOT SHOWN

Toilet components (fig. 2)

Ref.	Description
1	Rim flush check valve (freshwater toilet) or adapter (sea water model)
2	Water supply hose
3	Macerator pump (under plastic cover)
4	Electric water valve
5	Product ID label location
6	Stainless steel compression band
7	Discharge fitting



## Dometic Flush Toggle Switch

**Freshwater Flush** (toilet with DFST switch)

### Toilet system start-up

1. Turn on fresh water supply to toilet.
2. Press “Flush” switch (2) and hold for at least 10 seconds.
3. Toss several sheets of toilet paper into bowl and repeat cycle. The bowl should completely clear.

### Normal toilet operation

#### ADDING WATER TO TOILET BOWL

Press “Add Water” switch (1) and hold until desired water level is achieved. (Do not press “Add Water” switch too long or overflow may occur.)

#### FLUSHING TOILET

Press “Flush” switch (2) down and hold until waste drains from toilet bowl (about 10 – 20 seconds). This switch activates a macerator pump that siphons water and waste from the bowl, macerates, and propels the effluent to the discharge line/holding tank. To use less water for liquid-only flushes, press “Flush” switch for shorter period of time.

#### “DRY BOWL” OPERATION

During periods of rough travel, water in a toilet bowl can splash out and into the bathroom area. To avoid this situation, press “Dry Bowl” switch (3) to drain water completely from toilet bowl. Water is not added to bowl during or after pressing the “Dry Bowl” switch.



**Caution: Do not operate toilet without water supply turned on. Damage to internal components may occur.**

## Full Tank Monitor

- Your vessel is equipped with a waste tank level monitor and shut down relay which will disconnect power from the toilet when the waste tank becomes full. This is intended to prevent damage from flushing waste while the holding tank is already full.
- Pump out the waste holding tank to allow the marine head to reset the system and allow the marine head to flush again.
- When the waste holding tank is full, the LED Indicator shown below will light up.



Standard Dometic Tank Monitor

64




All Toilets are equipped with a “Full-tank” shut-down relay.

## DOMETIC OVERBOARD DISCHARGE

In addition to the Type III Waste System described previously, boats equipped with the overboard discharge system have the ability to manually pump waste tank contents directly overboard in unrestricted waters. (Consult Local and Federal Laws)

When Tank Monitor indicates "FULL" holding tank, follow the below steps to discharge contents.

1. Rotate Sea Cock to Open Position (Fitting and Handle are in-line)
2. Insert key into switch and turn to momentary "START" position. Allow key to return to "ON" position. (Green light indicates pump is running.)
3. When complete, the discharge pump will turn off automatically, and the Tank Monitor will indicate "EMPTY".
4. Turn key to left "OFF" position and remove from switch.
5. Return Sea Cock to Closed position. (Fitting and Handle are 90 deg offset.)



NOTE: When tank is not above "MID" Level, the pump will only run as long as key is held in momentary "START" position.



**All Toilets are equipped with a "Full-tank" shut-down relay.**

## Maintenance & Winterizing

### Cleaning the toilet

To maintain the toilet's original, lustrous appearance, use Dometic® Toilet Bowl Cleaner or other non-abrasive bathroom and toilet bowl cleaners. Please follow label directions.



#### Caution

To avoid damaging internal seals, do not clean toilet with abrasive cleaners, caustic chemicals, or lubricants and cleaners that contain alcohols or petroleum distillates.

### Routine maintenance

#### MONTHLY

1. Inspect toilet, plumbing, and plumbing connections, wires, and wire connections.
2. Open and close all plumbing valves, including seacocks.
3. Check in-line water filters and vented loops for blockage.

#### YEARLY

Check water valve filter. Also check water valve filter if water flow into toilet becomes insufficient.

### During extended periods of non-use

The macerator toilet and sanitation hoses should be protected if toilet will not be needed for an extended period of time (more than two weeks, especially in hot weather).

1. Flush toilet and add 4 oz. (118 ml) of liquid biodegradable laundry detergent (should NOT contain bleach or environmentally harmful substances). Note: If using sea water for flushing, shut off power to sea water pump and add fresh water directly into the bowl during the flush cycle.
2. Flush toilet at least five times.
3. Turn off water supply to toilet.
4. Flush the toilet without water very briefly to evacuate all water. (This procedure will minimize any remaining water in the macerator pump.)



#### Caution

During water evacuation process, do not operate sea water pump very long without water. Pump impeller may become damaged.

5. Turn off power to the toilet.
6. After extended periods of non-use, toilet and pump may dry. For easier re-start of toilet system, add one quart of water to bowl and let it stand for a few minutes before use.



#### Caution – Do Not Flush Foreign Objects!

Flush only water, bodily wastes and rapid-dissolving toilet tissue. Do not flush wet wipes, sanitary napkins, condoms, diapers, paper cups, cotton swabs, food, hair or liquids such as oils or solvents as clogging or damage to the toilet or toilet system may occur.



#### Note

Make sure all guests understand toilet operation before use.



## Maintenance & Winterizing

At the end of each season, the Dometic macerator toilet should be winterized for storage by using potable water-safe antifreeze (if boat or vehicle will be exposed to freezing temperatures).

If system will be subjected to freezing temperatures, please follow procedures in section 7.3, "During extended periods of non-use", and then winterize system as described here.



### Note

Use nontoxic antifreeze designated for potable water systems. (See boat or vehicle owner's manual.)



### Caution

Never use automotive-type antifreeze in freshwater systems.

### PRESSURIZED FRESH WATER SYSTEM

1. Drain potable water tank and empty holding tank.
2. Add freshwater antifreeze to potable water tank.
3. Flush potable water antifreeze and water mixture through toilet(s) and into entire system, including the waste holding tank, diverter valve connections, discharge pumps, etc. Turn off power to toilet.

Each installation is different, so amounts may vary. User discretion is required to assure adequate protection.

### SEA WATER SYSTEM

Parts required:

- Hose that fits sea water pump, about 3 ft. (1 m) long
- one container

1. Close intake and discharge seacocks. See Hazard of Flooding risks in this manual.
2. Turn off power to toilet.
3. Disconnect and drain intake hose and in-line filters.
4. Connect hose to sea water pump intake.
5. Place hose connected to pump intake into bucket with antifreeze in it.
6. Turn on power to toilet and flush until antifreeze is removed from toilet.
7. Disconnect power to toilet and reconnect all intake and drain hoses.

Access to the Electric Marine Head holding tank, hold tank's overboard discharge seacock and the optional A/C coolant water intake seacock is located in a hatch in the floor of the pilot's berth.

NOTE: This is a freshwater marine head system that runs off the boats freshwater tank, using the head will effect the boats freshwater supply.

## TROUBLESHOOTING

Problem	Possible Cause	Service Instruction
1. Flush function works, but water in bowl empties slowly or not at all.	<ul style="list-style-type: none"> <li>a. Discharge piping is pinched or kinked.</li> <li>b. Discharge piping is too high. (Remember, all upward vertical loops and should not exceed a total of 4 feet (1.2 m) in height.)</li> <li>c. The macerator pump or discharge piping is blocked.</li> </ul>	<ul style="list-style-type: none"> <li>a. Check discharge piping.</li> <li>b. Reroute discharge piping.</li> <li>c. Close seacocks and clear blockage.</li> </ul>
2. Macerator pump makes unusually loud noise or continually trips breaker.	<ul style="list-style-type: none"> <li>a. Foreign material in pump chamber.</li> </ul>	<ul style="list-style-type: none"> <li>a. Close seacocks and clear foreign material.</li> </ul>
3. Flush cycle is not activated after pushing on flush switch.	<ul style="list-style-type: none"> <li>a. Holding tank is full and signal from tank has shut down electrical power to toilet.</li> <li>b. Electrical power to toilet is shut off or disrupted.</li> <li>c. Flush switch is malfunctioning.</li> </ul>	<ul style="list-style-type: none"> <li>a. Empty holding tank.</li> <li>b. Check wiring and circuit breakers (or fuses).</li> <li>c. Replace flush switch.</li> </ul>
4. Insufficient or no water enters the bowl.	<ul style="list-style-type: none"> <li>a. Water supply line is pinched or kinked.</li> <li>b. Screen in water valve is blocked.</li> <li>c. Intake water filters are blocked (in sea water system).</li> <li>d. Water valve is malfunctioning.</li> </ul>	<ul style="list-style-type: none"> <li>a. Check water supply line.</li> <li>b. Clear blockage at water valve.</li> <li>c. Clear water filters.</li> <li>d. Replace water valve.</li> </ul>

## DOs

### Reactive & Preventative Cleaning

- Clean the material immediately if it comes in contact with substances like grease, blood, sauces, lipstick, wine, or coffee to prevent permanent stains and/or build-up.
- Clean at least once a week to extend the lifespan of the upholstery. This prevents dirt and other contaminants from building up and stains from becoming permanent. If there is a spill, wipe off any excess right away with a dry cloth, making sure not to spread it all over the surface.
- Clean the whole surface in circular motions using liquid hand soap (pH neutral) and water (1 part soap : 9 parts water). Wipe with a clean damp cloth to get rid of any excess soap. Repeat as needed and then let dry. Check the Spradling website for a complete list of approved cleaners. (<https://spradling.group/en-us/products/simtex?reference=Plata>)
- If there is any build-up that can't be removed with soapy water, then use this as a last resort. Mix 1 part isopropyl alcohol to 1 part water. (Using alcohol on a regular basis can affect the properties of the product.)
- Once a month, use a soft bristle brush for a deeper cleaning. Lighter colors need more care, more often.

## DON'Ts

### Techniques never to use

- Solvents like paint thinner, varsol, acetone, whiteners, waxes, silicones, detergents, and/or cleaning products that are not pH neutral.
- Products that are more than 50% alcohol.
- Never make marks on the product with pens or markers as it may absorb the ink and stain permanently.
- Cleaning tools like plastic or wire sponges, or hard-bristle brushes that can damage the material permanently.

69

### Remember

- It is important to note that this guide is not a warranty. It has recommendations for properly using and cleaning our upholstery products. Users are responsible for using and cleaning the coated fabrics safely with products that don't affect the surface, composition, or, as a result, their performance and lifespan.
- Cleaning results may vary depending on the size of the stain, cleaning product used, and time the surface is exposed.

The information provided is designed to give you a thorough understanding of the factors that can impact the appearance of your anodized aluminum. By using this information, we hope to help you enhance the beauty and value of our products.

## What Causes It?

Corrosion is a natural phenomenon that affects metals by either a chemical or electrochemical reaction. The rate at which aluminum corrodes depends greatly on the environmental conditions and the amount of preventative

maintenance performed. Our goal is to slow down or stop this natural phenomenon we call pitting (or corrosion).

## Anodized Aluminum

The aluminum on your boat has been anodized. This creates a very hard protective seal on the surface of the aluminum to protect it as much as possible from pitting. When the anodized coating is broken and raw aluminum is exposed, corrosion will take place. Damage from other abrasive impacts can break the anodized coating.

## Chemical Attack

Corrosive chemicals containing high concentrations of acids or alkalis will remove the anodized coating. Solutions containing chlorine, salts, or ammonia are all harmful to the anodized aluminum on your boat. Many common household cleaners contain chemicals that will remove the anodizing and cause pitting.

AVOIDABLE	UNAVOIDABLE
Strong acidic solutions found in cleaners, paint remover, degreasers, etc.	Airborne pollution. Airborne particles from local sources: vehicles, incinerators, paper mills, chemical plants, power plants, etc.
Concentrated alkaline based solutions. Many concentrated soaps fall into this category.	Harsh chemicals from work performed at local shipyards and dry docks.
Chlorine, sulfurs, solvents and ammonia based products.	Be aware of local sources that can expose your new boat to corrosive chemicals.





## Tips

Avoid the use of bleach or chlorides to clean the aluminum or nearby components. Chlorides can leach onto the aluminum when used nearby.

Avoid abrasive cleaning products. Never use steel or brass wool, wire brushes, polishing wheels, rubbing or polishing compounds. These items will remove the anodizing and lead to pitting.

## Protective Products

There are many different products available to protect aluminum. Some are designed to seal and protect before problems occur and others are designed to use after pitting has appeared.

While these products are effective, they are not one time solutions. Metal protectors must be reapplied on a regular basis. How often a protector should be used varies according to the protector you choose, the types of exposure your

boat is subjected to, and how often you use and wash your boat. Follow the application guidelines provided with the protector you choose.

## Harmful Cleaners

Bleach (Chlorox, etc.)  
Mild abrasive cleaners (Ajax, Comet, Soft Scrub, Rubbing Compounds, etc.)  
Strong cleaners (409, Engine Degreasers, Bilge Cleaners, Teak Cleaners, Bottom Cleaners, etc.)



### Below are some metal protection products that are readily available at marine retailers.

Woody Wax CPR	Woody Wax woody-wax.com 800-619-4363
Boeshield T-9	PMS Products, Inc. boeshield.com 800-962-1732
Premier Polish	Aquatech aquatech-marine.com 800-853-7760
Corrosion Block	Lear Chemical learchem.com 800-256-2548

The information provided is designed to give you a thorough understanding of the factors that can impact the appearance of your stainless steel. By using this information, we hope to help you enhance the beauty and value to our products.

## **What Makes Stainless Steel Stainless?**

Oxygen is the key element in causing rust, or red oxide on steel and other metals. Stainless Steel contains Chromium which reacts with the oxygen in the air to form a chrome-oxide surface layer that is invisible to the eye, but strong enough to prevent further oxygen from "staining" (rusting) the surface. Higher levels of Chromium and the addition of other alloying elements such as nickel and molybdenum enhance this surface layer and improve the corrosion resistance of the stainless material.

## **What Determines Different Grades of Stainless Steel?**

The grade of Stainless Steel is primarily determined by the amount of the Chromium and Nickel alloys contained in the material. 304 and 316 are the prominent grades of Stainless Steel: 304 contains 1% Chromium and 8% Nickel, while 316 Contains 16% Chromium and 10% Nickel and 2% Molybdenum. The Molybdenum is added to help resist corrosion to chlorides (like sea water and de-icing salts).

## **Can Stainless Steel rust?**

Not in the way steel rusts. Steel will discolor, bubble and flake from red oxide development. Stainless Steel may develop red spots, but this is usually due to Iron particles on the surface of the Stainless Steel. Any Iron particles must be removed and the Stainless Steel cleaned with a high concentration of citric acid or a commercial cleaner specifically designed for Stainless Steel.

## **Is Stainless Steel Green (Environmentally Friendly)?**


Stainless Steel is highly sought after by recyclers and is 100% recyclable. New Stainless Steel typically has a recycled content of between 65% & 80% which makes it one of the highest average content recycled construction materials on the planet.

## **Will Stainless Steel Discolor?**

Cleaners that are typically used with cement, grout and stone, etc., may contain Muriatic Acid. Stainless Steel is not resistant to Muriatic Acid. MURIATIC ACID SHOULD NOT BE USED IF STAINLESS STEEL IS PRESENT. It is not even necessary that the acid touch the Stainless Steel, just the "fumes" from it will cause a discoloration of the Stainless Steel. Other than this, Stainless Steel is usually very resistant to discoloring.

## SAILFISH 360 CC | OWNER'S MANUAL - WINDSHIELD WASHING & CARE

1. If you have been offshore, be sure to spray the windshield liberally with a hose to melt and wash away any salt crystals.
2. Use commercially available glass cleaners or a mixture of fresh water and vinegar. Do not use abrasives, harsh chemicals, or metal scrapers. Regular cleaning will help assure clarity of the glass for safe boating.
3. The Windshield Washer Fluid Reservoir is located behind the 4 hatches in the head/berth.



## Your Boat's Gel Coat Finish

Congratulations! You are the proud owner of a new Sailfish. You are also the owner of a new gel coat finish on the hull and/or topside, and we would like you to be as proud of it as we are. That beautiful, shiny new color you love is the result of many years of gel coat research, testing and development.

But as proud as we are of the gel coat, no finish is totally impervious to chemicals and weathering. Imagine what a brand new car could look like if allowed to sit at a marina for years with no cover and no washing or waxing. With the same minimum maintenance you would ordinarily give your new automobile's finish, your boat's gel coat finish will retain its depth of color and gloss for years.

## Overall Maintenance

Normal maintenance of your gel coated fiberglass boat is similar to the care you would give your automobile. Overall, automotive cleaners and waxes work fine, as well as the marine cleaners and waxes.

Note: Do not use caustic or highly alkaline (high pH) cleaners or those containing ammonia. These type of cleaners may darken white or off-white weathered gel coat surfaces. A chemical reaction producing staining occurs if these type of cleaners are used on weathered gel coat. However, the stain may be removed with a rubbing compound or by lightly sanding with 400 grit sandpaper followed by an application of rubbing compound and a thorough waxing.

## Cleaning

We recommend general washing to avoid soil build-up and staining. The soil to your gel coat is the result of regular use and environmental pollutants such as soot and smog. Periodic cleaning with a mild detergent is necessary to remove normal deposits of soil.

## Waxing

From constant exposure over time to our natural environment and undesired pollutants, the gel coat begins to lose its gloss. To restore your finish to the original gloss and color requires your special attention. After washing with a mild soap or detergent, give the surface a good

polishing with a self-cleaning marine or automotive wax. Waxing in the fall and spring is generally recommended to maintain and restore most of the original gloss. If the surface has not been maintained and has weathered badly, and if cleaning and waxing does not restore the finish satisfactorily, compounding will be required.

## Compounding

Please see your marine dealer for advice. Polishing and compound (fine abrasive) or rubbing compound (coarser abrasive) is recommended for use on fiberglass boats to remove scratches, stains, or a severely weathered surface. Polishing or rubbing compound can be applied by hand or by pneumatic buffer. After the scratched, stained or weathered surface has been removed, it should be waxed to enhance the gloss and color while providing a seal to retard staining or new soil accumulation.

## Discoloration Removal

Your marine dealer is best equipped and trained to do this work. If regular washing and waxing has been neglected, discoloration of the gel coated fiberglass surface may occur.



Discolored areas are very shallow in depth, literally right on the surface. The discoloration may be removed by gently wet-sanding the affected areas only by using 600 grit, wet or dry specially treated waterproof sandpaper. It's important to always sand in one direction, this includes the curves too. Use plenty of water to cool and clean the sandpaper and cut back on dust. After you are finished sanding, dry the areas and verify all the discoloration has been removed. If not, repeat the process.

After all the discoloration has been removed, the area will need to be buffed. Using an electrical or pneumatic buffer, buff at low speed (1750 rpm – 2250 rpm), this will restore the luster to the sanded surface. Using a generous amount of rubbing compound, apply it in a circular motion with a soft wool pad. When buffing has been completed, wash off the rubbing compound with clean water, and dry the surface.

To restore the gloss to the affected area, use a high-grade marine or automotive wax.

## Repairs

During the life of your boat, some damage to the gel coat surface is unavoidable. We recommend repairs done by trained, experienced professionals at your local marine dealer.

## Scratches

If the scratch is in the gel coat surface, not penetrating the fiberglass, use an automotive polishing compound and rub it out. Apply the compound by hand using a damp rag or by using a power buffer. The scratch may not entirely disappear, but it should be noticeably better.

## Gouges and Chips

Our recommended patching procedure is to first clean the area needing repair with an acetone solvent to remove all traces of wax and oil. Next, thoroughly mix one tablespoon of "Patch Paste" with two or three drops of catalyst on a scrap piece of cardboard.

Apply the mixture to the pit, chip or gouge with a single-edge razor blade, matching the surface and contour of

the area being repaired. Apply slightly more mixture to avoid having to fill the damaged section a second time. Allow the patch to harden thoroughly for a minimum of two to three hours.

Using a fine grit "wet or dry" sandpaper on a sanding block, wet-sand the patch until it is level with the surrounding surface. Finish with a marine or automotive rubbing compound using the same approach as used for the scratches.

## Refinishing

For a severely scratched or weathered fiberglass boat that is no longer restorable by using the previous methods, it may then be necessary to refinish it with two-package or two-part aliphatic urethane enamel. This can be done very effectively, but it is recommended refinishing should only be done by experienced professionals.

75





# SAILFISH 360 CC | SAILFISH BOATS LIMITED WARRANTY

SEMINOLE MARINE INC. ("Sailfish" producer of Sailfish Boats warrants to you, the first retail purchaser of a new boat bought from a factory authorized dealer, that it will repair or replace defects in materials or workmanship that occur and are reported to your factory authorized dealer within the applicable Warranty Periods set forth below, subject to the terms, conditions and exclusions ("What This Warranty Does NOT Cover") set forth below. Your acceptance of delivery of the warranted boat constitutes your acceptance of the terms of this limited warranty. All warranty periods run from the date (the "Effective Date") of delivery to the original retail owner (the "Owner"), or twelve (12) months from the date the boat was delivered to the Sailfish dealer, whichever is earlier. This limited warranty applies only to covered defects first arising and reported to Sailfish or its authorized dealer within the applicable warranty coverage period.

U.S. purchasers: this warranty gives you specific legal rights, and you may also have other rights which vary from state to state. E.C. purchasers: the owner has legal rights under applicable national legislation and the Consumers Protective Directive 1999/44/EC of the European Parliament and of the Council of 25 May 1999 governing the sale of consumer goods, and those rights are not affected by this limited warranty. Any claim that the boat was nonconforming at the time of delivery must be made within two (2) years from the date of delivery.

## **WHAT THIS WARRANTY COVERS:**

Structural Warranty: Structural fiberglass defects in workmanship and materials in the hull, stringers, transom causing the boat to be unfit for general use as a pleasure craft under normal conditions of operation - Limited Original Purchaser's Ten (10) years.

Component Warranty: For defects in workmanship and materials in factory manufactured and installed non-structural parts and components - One (1) year Limited Warranty.

The applicable Warranty Period runs from the date of delivery of the boat to the first retail customer, and warranty coverage applies only to warranted claims that first arise and are reported to Sailfish within the applicable warranty period. This warranty extends only to the first retail purchaser.

The express limited warranty described above is the sole and exclusive express warranty from Sailfish. **Under the laws of certain states, there may be no implied warranties or conditions from Sailfish applicable to your boat, and all implied warranties (INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) and conditions are excluded and disclaimed from warranty coverage where allowed by law. Any IMPLIED WARRANTIES (if any) arising under applicable law are LIMITED IN THEIR DURATION TO TWO (2) YEARS FROM THE EFFECTIVE DATE.**

ALL IMPLIED WARRANTIES, if any, INCLUDING **MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE ARE EXCLUDED AND DISCLAIMED** IN THEIR ENTIRETY

AFTER TWO (2) YEARS FROM THE EFFECTIVE DATE. There are no warranties which extend beyond the description on the face hereof. **Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.**

## **WHAT THIS WARRANTY DOES NOT COVER:**

Sailfish does not provide any warranty coverage, nor have any liability or responsibility, for any defects, costs, expenses or damages relating to the following:

- The failure to use, maintain or store the boat as specified in the manuals supplied to the Owner;
- A boat purchased from anyone other than an authorized dealer;
- A boat, including its components, that has been altered, modified or not properly maintained;
- A boat, including components and systems, that has been altered or modified from factory specifications; equipment and accessories not factory installed by Sailfish;
- Engines, outdrives, controls, propellers, batteries, generators, appliances, air conditioners, stereos and other equipment or accessories that are not manufactured by Sailfish, whether or not warranted by other manufacturers. It is the owner's obligation to fulfill any warranty registration and other obligations as to any third-party manufacturer's warranty coverage, and to submit any warranty claims directly to the third-party warrantor. Note: it is the Owner's responsibility to complete any OEM warranty registration procedure that may be applicable;
- Non-structural parts and components manufactured or installed by third parties, whether or not warranted by other manufacturers;
- The cost of removal or reinstallation of parts or disassembly of units to repair or replace components covered by this limited warranty;



# SAILFISH 360 CC | SAILFISH BOATS LIMITED WARRANTY

- Any boat which has been in an accident, misused, used in a negligent manner, used for racing, used for rental, charter, demo, military, rescue, fire, safety, medical, police, law enforcement, patrol, or other governmental or commercial purposes, operated contrary to any instruction furnished by Sailfish, or operated in violation of any governmental or agency laws, rules or regulations;
- Fiberglass blistering attributable to water penetration of the fiberglass (osmotic blistering);
- Any representation relating to speed, range, fuel consumption or other estimated performance characteristic;
- Loss of time, inconvenience, boat payments, retail charges, improper lifting or trailering, travel expenses, loss of use, in-and-out-of-water charges, towing and storage charges, loss of or damage to personal property, or other remedies not specifically allowed;
- Damage from osmosis blistering if the original gel surface has been altered in any way;
- Damage or deterioration of cosmetic surface finishes, including corrosion, cracking, crazing, discoloration, fading, rusting or oxidation of gel coat and painted fiberglass surfaces, wood finishes (varnishes, stains and paints), fabrics, plated or painted/powder coated metal and stainless steel finishes; anti-fouling bottom paint or zinc anodes;
- The cost to remove, disassemble or reinstall components not installed by Sailfish that require removal to access parts covered by this limited warranty;
- Dealer preparation, cleaning, final adjustments and alignments in preparing the boat for delivery or commissioning;
- Normal and routine maintenance and wear and tear, including leakage around windshield, hatches, canvas, or other designated openings;
- Window glass and windshield damage, leaks or breakage; damage, shrinkage or deterioration of carpet, upholstery, and exterior canvas tops, enclosures, and weather covers;
- Fit and adjustment of exterior canvas tops, enclosures and weather covers;
- Sacrificial deterioration of anti-fouling paint or zinc anodes; or
- Cosmetic and/or damage resulting from normal wear and tear, or improper care and maintenance, either by dealer prior to consumer purchase or by consumer are not covered.

## **REMEDIES AND OTHER INFORMATION:**

Your **sole and exclusive remedy** (including any applicable implied warranty) is the repair or replacement, at Sailfish sole option, of parts and components covered by this warranty, **and does not include incidental or consequential damages which are specifically DISCLAIMED and EXCLUDED from warranty coverage**. U.S. purchasers: some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Any legal action alleging a breach of warranty must be brought within one (1) year from the date the alleged breach first occurred, regardless of the time remaining in the applicable warranty period. The boat, including any alleged defective part, must be returned to an authorized dealer (or as otherwise directed by Sailfish) within the applicable warranty period to obtain warranty service. The authorized dealer will carry out the warranty procedures on the owner's behalf. All warranty work will be performed at an authorized dealer, another repair facility that Sailfish selects, or the factory, at Sailfish' option. The owner is responsible for the expense associated with transporting the boat to and from the repair facility.

This document contains the entire warranty given by Sailfish and there are no terms, promises, conditions or warranties regarding your Sailfish other than those contained herein. Sailfish reserves the right to change Sailfish specifications, features, and prices without prior notification and without obligation for Sailfish previously manufactured.

Your acceptance of delivery of the warranted Sailfish constitutes your acceptance of the terms of this limited warranty. Your Sailfish dealer is an independent business and is not the agent of Sailfish. Your Sailfish dealer may not modify or change the terms of this limited warranty, and any questions concerning the scope of this limited warranty coverage should be addressed directly to Sailfish. Neither your Sailfish dealer nor anyone else is authorized to extend the time or scope of this warranty, or to create or assume for Sailfish any other obligation or liability with respect to Sailfish or this warranty.

Any legal action alleging a breach of this warranty (or any implied warranty) must be brought within one (1) year from the date the alleged breach first occurred. The exclusive jurisdiction and venue for any court action commenced by you under or relating to this limited warranty or any implied warranty(ies) shall be in the Circuit Court for Grady County, Georgia or United States District Court for the Middle District of Georgia.

We may be contacted as follows: Sailfish Boats, Attention: Customer Service Department, 2501 Industrial Park Drive, Cairo, GA 39828, USA. +1-229-377-2125.



[SAILFISHBOATS.COM](https://www.sailfishboats.com)

Specifications, features, equipment, options, colors, materials and trim are based on information available at time of printing and are subject to change without notice. Some accessories shown in photographs, or described, may not be standard equipment or even available as an option(s). Confirm availability of all accessories and equipment with an authorized Sailfish Boats dealer prior to purchase.

© 2025 Sailfish Boats.